

# **TRA1 80A Transformer**




**TRA1 80A transformers** are current transformers specially designed for being installed at the top of a circuit breaker. All the models have secondary of 250 mA and are suitable for SKM8, SKT8 and third-party devices.

**TRA1 80A transformers** are perfect for facilities with reduced spaces, using the space over the differential protections. Furthermore, TRA1 Transformers series are ideal for facilities whether it is not possible to stop the supply, or it just need a simple installation.

### TECHNICAL FEATURES

Electrical features	
Frequency	50 / 60 Hz
Secondary's current	250 mA
Measure	Single phase
TRA1 series power class	3
Build features	
Type of enclosure material	Epoxy

### **CONNECTIONS**




### INSTALLATION

The installation of the transformers must be done at the top of the circuit breaker protections.



### **GRAPHIC REPRESENTATIONS AND DIMENSIONS**



#### TRA1 SERIES REFERENCES

Model	Reference	Maximum current	Accuracy class	Inner diameter
TRA1 20A	T024	20 A	3	16 mm
TRA1 80A	T004	80 A	3	10 mm
TRA1 100A	T005	100 A	3	16 mm
TRA1 250A	T025	250 A	3	24 mm

#### SAFETY PRECAUTIONS



## **DANGER**

Incorrect handling or installation of the unit may result in injury to personnel as well as damage to the unit. In particular, handling with voltages applied may result in electric shock, which may cause death or serious injury to personnel. Defective installation or maintenance may also lead to the risk of fi re. Read the manual carefully prior to connecting the unit. Follow all installation and maintenance instructions throughout the unit's working life. Pay special attention to the installation standards of the National Electrical Code.

#### DISCLAIMER

Disibeint reserves the right to make modifications to the device or the unit specifications set out in this instruction manual without prior notice.

Disibeint on its web site, supplies its customers with the latest versions of the device specifications and the most updated manuals.

# TECHNICAL SERVICE AND SUPPORT

The unit does not require maintenance.

In case any doubt of performance or failure of the unit do not hesitate to contact with Disibeint support service.

Disibeint Electronic SL Segle XX Street, 91 08032 – Barcelona (Barcelona), SPAIN Phone: (34) 934 560 995 (Spain)

Email: disibeint@disibeint.com