

INTERFACE	
Code	Value
<b>9</b>	With display 3 basic languages: Spanish, English, French 1 optional language (by default, Catalan)
<b>Q</b>	Without display Without communication
<b>U</b>	Without display RS232 or RS485 communication

Nr. RELAYS	
Code	Value
<b>0</b>	Without relays
<b>3</b>	3 relays

TYPE OF RELAYS	
Code	Value
<b>0</b>	Without relays
<b>A</b>	SPST NA

COMMUNICATION	
Code	Value
<b>0</b>	Without bus
<b>4</b>	4-20 mA
<b>3</b>	RS232
<b>8</b>	RS485

DC SUPPLY VOLTAGE	
Code	Value
<b>712</b>	12 V
<b>724</b>	24 V
<b>748</b>	48 V
<b>772</b>	72 V
<b>125</b>	125 V

AC SUPPLY VOLTAGE	
Code	Value
<b>024</b>	24 V
<b>048</b>	48 V
<b>110</b>	110 V
<b>230</b>	230 V
<b>400</b>	400 V
<b>440</b>	440 V
<b>500</b>	500 V

AC/DC SUPPLY VOLTAGE With galvanic isolation	
Code	Value
<b>903</b>	15..70 V
<b>904</b>	60..240 V

LEVEL RANGES	
Code	Value
<b>80N</b>	1..80 niveles

CURRENT RANGES	
Code	Value
<b>2MA</b>	2 mA
<b>A02</b>	20 mA
<b>A20</b>	200 mA
<b>1A</b>	1 A
<b>5A</b>	5 A
<b>10A</b>	10 A
<b>V15</b>	150 mV

DC VOLTAGE RANGES	
Code	Value
<b>12V</b>	12 VDC
<b>24V</b>	24 VDC
<b>48V</b>	48 VDC
<b>72V</b>	72 VDC
<b>125</b>	125 VDC

AC VOLTAGE RANGES	
Code	Value
<b>110</b>	110 VAC
<b>230</b>	230 VAC
<b>400</b>	400 VAC
<b>440</b>	440 VAC
<b>500</b>	500 VAC
<b>690</b>	690 VAC
<b>8500</b>	8..500 VAC